

SW1	Sw1	Sw2	Sw3	Sw4	Sw5	Sw6	Sw7	Sw8
Top bonus 300 up	OFF							
Top bonus 600 up	ON							
Down bonus 300 up		OFF						
Down bonus 600 up		ON						
Probability 80%			OFF	OFF				
Probability 85%			ON	OFF				
Probability 90%			OFF	ON				
Probability 95%			ON	ON				
Double-up 85%					OFF			
Double-up 90%					ON			
1 coin 1 credit							OFF	OFF
1 coin 5 credits							ON	OFF
1 coin 10 credits							OFF	ON
1 coin 20 credits							ON	ON
SW2	Sw1	Sw2						
Single bet 10 as max	OFF	OFF						
Single bet 20 as max	ON	OFF						
Single bet 30 as max	OFF	ON						
Single bet 40 as max	ON	ON						
Demo music On			OFF					
Demo music Off			ON					

Buttons functions:

K3 : Audit: Press and hold "K3", and restart. Press "Start" buttons to audit
 Number will be shown on column of "red BAR".
 00-total profits
 01-total bets
 02-total numbers of winning
 03-total numbers of double-up
 04-total winning numbers of double-up
 05-probability
 06-probability of double-up

K2: press and hold "K2" to restart, after "88" displayed on screen, restart again.
 (Necessary to reset when adjust low probability to higher)

K1: coins counting, press and hold "K1", then restart. Push "paid out" button to show 500.
 To increase or decrease numbers by pushing "big" and "small" buttons on
 Double-up(ex: show 500, press "paid out" button to count 500 coins)



Error codes: 33-breakdown of coin selector — *monedero*
55-breakdown of key-out switch — *sensor*
66: breakdown of PCB or data
99: Reset when profits over 50,000

JP1	
1	X
2	GND
3	GND
4	X
5	GND
6	Coin count NC
7	Key-out SW
8	X
9	X
10	+5V

JP2	
1	+5V
2	+5V
3	GND
4	GND
5	SSR
6	+12V

JP4	
1	Count meter In
2	Count meter out
3	+5V
4	X
5	Count meter In +12V
6	Count meter out +12V
7	SOUND OUT
8	SOUND GND
9	Coin inserted NC
10	Coin inserted GND

JP5	
1	Com0
2	Com1
3	RL0
4	RL1
5	RL2
6	RL3
7	RL4
8	RL5
9	RL6
10	RL7

