

NEW Tarzan									
DIP-SW		1	2	3	4	5	6	7	8
BET RATIO	1 = 1	OFF	OFF						
	2 = 1	ON	OFF						
	5 = 1	OFF	ON						
	10 = 1	ON	ON						
DOUBLE PLAY	left and right			ON					
	numeral			OFF					
PAY	YES				ON				
	NO				OFF				
MAX BET	50					ON			
	10					OFF			
DEMO MUSIC	YES						ON		
	NO						OFF		
COIN SCORE	1 = 1							ON	ON
	1 = 2							OFF	OFF
	1 = 5							OFF	ON
	1 = 10							ON	OFF

[K1]: Account

[K2]:Setting % . Number

[K2]+[K4]:Counting coins

[K1]+[K2] :RESET



[K1]:Account

0,1,2,3,4 = The accounts

5,6,7,8,9 = Last accounts

10 = total win score

(0):win score(1)-(2)+(3)-(4)=(0)

(1):total bet score

(2):total get score

(3):double score



(4):double get score

(10):total win score

[K2]:Setting % . Number

Fuccion Operation

Start Button:Next




double% { Number }

game%

double% : <= Button (+) , =>Button (-)

game% : Big Button (+) , small Button (-)

[K2]+[K4]:Counting coins



<= Button (+) , =>Button (-) , PAY Button

Error Message

[00],[01],[77]:IC Error[RESET]

[02]:Counter Error

[03],[04]:Memory Error[RESET]

[08]: Account(0)=500000[RESET]

[09]:Account(10)=500000[RESET]

[30]:Orange Lighting ,coin sw [NO , NC] Error

[30]:Bell Lighting ,H P sw [NO , NC] Error

[30]:77 Lighting ,H P No coins

[76]:KEY OUT SW Error